

[English]

SilkyEvCam Plugin for Metavision® Setup Guide

The following settings are required to use the Metavision® application with SilkyEvCam (VGA / HD / HD Lite).
The Windows version of the plugin file (zip) comes with metavision_viewer pre-installed. (See the website below.)
<https://centuryarks.com/en/silkyevcam-hd/#anchor04>

[Plug-in install]

1. Download the plug-in setup file (zip) from the CenturyArks download site below.
*Please download the file according to the version of Metavision® applicaion you are using.
<https://centuryarks.com/en/download/>

2. Download file and startup confirmation

2-1. [Ubuntu]

- SilkyEvCam_Plugin_Installer_for_ubuntu_v??.?.zip

Please refer to the “readme.txt” file included in the above file for the setup procedure.

- Connect SilkyEvCam to your PC with a USB cable, start metavision_viewer and check that streaming images are output. *The following steps [Metavision® Install] are required to start the application.
(ex.)

```
>/usr/(local/)bin/metavision_viewer [Enter]
```

2-2. [Windows]

- SilkyEvCam_Plugin_Installer_for_win64_v??.?.zip

Please refer to the “readme.txt” file included in the above file for the setup procedure.

- Connect SilkyEvCam to your PC with a USB cable, start metavision_viewer.exe from the application menu, and check that the streaming image is output.

(ex.)

```
[START] - [CenturyArks] - [Metavision Viewer]
```

[Metavision® install]

1. Access the PROPHESEE website below and install the Metavision® SDK*1 or download and compile OpenEB sources*2 according to your PC's OS (Windows/Linux).

<https://docs.prophesee.ai/stable/installation/index.html>

※Please check the required OS on the above site.

*1 Metavision® SDK is an application that must be purchased separately from the SilkyEvCam (VGA/HD/HD Lite).

*2 For Linux, the OpenEB packages are also available as well as its sources.

Manufacturer: CenturyArks Co., Ltd.

Location: 3-13-1 Nishi-Azabu, Minato-ku, Tokyo 106-0031 TEL: +81-3-6804-5752

Web site: <https://www.centuryarks.com/>

Product Inquiries Email: ca-qa@centuryarks.com



Metavision SDK

[Japanese]

SilkyEvCam Metavision®用プラグイン セットアップガイド

SilkyEvCam (VGA / HD / HD Lite)で Metavision® アプリケーションを使用するには、次の設定が必要です。
Windows 版のプラグインファイル(zip)には metavision_viewer がプリインストールされています。(下記サイト参照)
<https://centuryarks.com/silkyevcam-hd/#anchor04>

[プラグインファイル インストール]

1. 下記 CenturyArks のダウンロードサイトからプラグインセットアップファイル(zip)をダウンロードしてください。
※ご使用の Metavision® アプリケーションのバージョンに沿ったファイルをダウンロードしてください。
<https://centuryarks.com/download-2/>

2. ダウンロードファイル及び起動確認

2-1. [Ubuntu]

- SilkyEvCam_Plugin_Installer_for_ubuntu_v??.?.zip

セットアップ手順は上記ファイルに含まれる"readme.txt"ファイルを参照してください。

- SilkyEvCam を USB ケーブルで PC に接続し、metavision_viewer を起動してストリーミング画像が出力されることを確認します。 ※起動には下記 [Metavision® インストール] の対応が必要です。

(例)

```
>/usr/(local/)bin/metavision_viewer [Enter]
```

2-2. [Windows]

- SilkyEvCam_Plugin_Installer_for_win64_v??.?.zip

セットアップ手順は上記ファイルに含まれる"readme.txt"ファイルを参照してください。

- SilkyEvCam を USB ケーブルで PC に接続し、アプリケーションメニューから metavision_viewer.exe を起動してストリーミング画像が出力されることを確認します。

(例)

```
[スタート] - [CenturyArks] - [Metavision Viewer]
```

[Metavision® インストール]

1. 下記 PROPHESEE 社の Website へアクセスし、PC の OS(Windows/Linux)に合わせて Metavision® SDK*1 のインストールまたは OpenEB ソースファイル*2 をダウンロードしてコンパイルします。

<https://docs.prophesee.ai/stable/installation/index.html>

※対応する OS は上記サイトで確認してください。

*1 Metavision® SDK は本製品とは別に購入が必要なアプリケーションです。

*2 Linux については OpenEB パッケージ版も公開されています。

Metavision SDK とは



製造元: (株)センチュリーアークス

所在地: 〒106-0031 東京都港区西麻布 3 丁目 13-1 TEL : 03-6804-5752

弊社ホームページ: <https://www.centuryarks.com/>

製品に関するお問い合わせメールアドレス: ca-qa@centuryarks.com