

[English]

## METAVISION™ HAL Plugin Setup Guide

The following settings are required to use the Metavision™ Intelligence suite application with SilkyEvCam.

0. Access the following PROPHESEE website, enter the required information, and then install the Metavision™ Intelligence suite according to your PC environment.

<https://www.prophesee.ai/metavision-intelligence-essentials-download/>

※Compatible with Ubuntu 18.04 64-bit or Windows 10 64-bit.

### [Ubuntu 18.04 64-bit]

1. Download the following files from the CenturyArks product site.  
<https://www.centuryarks.com/products/sensor/silkyevcam>  
-SilkyEvCam\_G31\_Installer\_for\_ubuntu\_v??.?.zip \*Latest version
2. Unzip the downloaded zip file and run the installer file.  
> unzip SilkyEvCam\_G31\_Installer\_for\_ubuntu.zip [return]  
> cd SilkyEvCam\_G31\_Installer\_for\_ubuntu\_v??.? [return]  
> ./CA\_Silky\_installer.sh [return]
3. Connect SilkyEvCam to your PC with a USB cable, start metavision\_player and check that the streaming image is output.  
> metavision\_player [return]

### [Windows 10 64-bit]

1. Download the following files from the CenturyArks product site.  
<https://www.centuryarks.com/products/sensor/silkyevcam>  
- SilkyEvCam\_G31\_Installer\_for\_win64\_v??.?.zip \*Latest version
2. Unzip the downloaded zip file and run the installer file.  
> SilkyEvCam\_G31\_Installer\_for\_win64\_v??.?.exe
3. Connect SilkyEvCam to your PC with a USB cable, start metavision\_player.exe from the application menu, and check that the streaming image is output.  
>metavision\_player.exe

-----  
Manufacturer: CenturyArks Co., Ltd.

Location: 3-13-1 Nishi-Azabu, Minato-ku, Tokyo 106-0031 TEL: +81-3-6804-5752

Web site: <https://www.centuryarks.com/>

Product Inquiries Email: [ca-ga@centuryarks.com](mailto:ca-ga@centuryarks.com)