

[English]

## METAVISION® Intelligence suite Plugin Setup Guide

The following settings are required to use the Metavision® Intelligence suite application with SilkyEvCam (VGA) / SilkyEvCam HD / SilkyEvCam HD Lite.

### [ Metavision® Intelligence install ]

0. Access the PROPHESEE website below, enter the required information, and install Metavision® Intelligence suite according to your PC's OS.

<https://docs.prophesee.ai/4.6.2/installation/index.html>

※Please check the required OS on the above site.

### [ Plug-in install ]

1. Download the plug-in setup file (zip) from the CenturyArks download site below.  
\*Please download the file according to the version of Metavision® Intelligence suite you are using.

<https://centuryarks.com/en/download/#v462>

2. Download file and startup confirmation

#### 2-1. [ Ubuntu ]

##### - SilkyEvCam\_Plugin\_Installer\_for\_ubuntu\_v??.?.zip

Please refer to the "readme.txt" file included in the above file for the setup procedure.

- Connect SilkyEvCam to your PC with a USB cable, start metavision studio and check that streaming images are output.

> metavision\_studio [return]

#### 2-2. [ Windows ]

##### - SilkyEvCam\_Plugin\_Installer\_for\_win64\_v??.?.zip

Please refer to the "readme.txt" file included in the above file for the setup procedure.

- Connect SilkyEvCam to your PC with a USB cable, start metavision\_studio.exe from the application menu, and check that the streaming image is output.

>metavision\_studio.exe

---

Manufacturer: CenturyArks Co., Ltd.

Location: 3-13-1 Nishi-Azabu, Minato-ku, Tokyo 106-0031 TEL: +81-3-6804-5752

Web site: <https://www.centuryarks.com/>

Product Inquiries Email: [ca-qa@centuryarks.com](mailto:ca-qa@centuryarks.com)