

[English]

METAVISION™ HAL Plugin Setup Guide

The following settings are required to use the Metavision™ Intelligence suite application with SilkyEvCam / SilkyEvCam HD.

0. Access the following PROPHESEE website, enter the required information, and then install the Metavision™ Intelligence suite according to your PC environment.

<https://www.prophesee.ai/metavision-intelligence-essentials-download/>

※Compatible with Ubuntu 18.04 / 20.04 64-bit or Windows 10 64-bit.

[Ubuntu 18.04 /20.04 64-bit]

1. Download the following files from the CenturyArks product site.
<https://centuryarks.com/en/download/>
-SilkyEvCam_(G31/HD)_Installer_for_ubuntu_v??.?.zip *Latest version
2. Unzip the downloaded zip file and run the installer file.
> unzip SilkyEvCam_(G31/HD)_Installer_for_ubuntu_v??.?.zip [return]
> cd SilkyEvCam_(G31/HD)_Installer_for_ubuntu_v??.? [return]
> ./CA_Silky_installer.sh [return]
3. Connect SilkyEvCam / SilkyEvCam HD to your PC with a USB cable, start metavision_studio and check that the streaming image is output.
> metavision_studio [return]

[Windows 10 64-bit]

1. Download the following files from the CenturyArks product site.
<https://centuryarks.com/en/download/>
- SilkyEvCam_(G31/HD)_Installer_for_win64_v??.?.zip *Latest version
2. Unzip the downloaded zip file and run the installer file.
> SilkyEvCam_(G31/HD)_Installer_for_win64_v??.?.exe
3. Connect SilkyEvCam / SilkyEvCam HD to your PC with a USB cable, start metavision_studio.exe from the application menu, and check that the streaming image is output.
>metavision_studio.exe

Manufacturer: CenturyArks Co., Ltd.

Location: 3-13-1 Nishi-Azabu, Minato-ku, Tokyo 106-0031 TEL: +81-3-6804-5752

Web site: <https://www.centuryarks.com/>

Product Inquiries Email: ca-qa@centuryarks.com