

[English]

## METAVISION™ Intelligence suite Plugin Setup Guide

The following settings are required to use the Metavision™ Intelligence suite application with SilkyEvCam (VGA) / SilkyEvCam HD.

### [ Metavision™ Intelligence install ]

0. Access the PROPHESEE website below, enter the required information, and install Metavision™ Intelligence suite according to your PC's OS.

<https://docs.prophesee.ai/stable/installation/index.html>

※Operating system : Ubuntu 18.04 / 20.04 64-bit or Windows 10 64-bit.

### [ SilkyEvCam (VGA) / SilkyEvCam HD Plug-in install ]

1. Download the plug-in setup file (zip) from the CenturyArks download site below.

\*Please download the file according to the version of Metavision™ Intelligence suite you are using.

<https://centuryarks.com/en/download/>

2. Download file and startup confirmation (common to SilkyEvCam (VGA) / SilkyEvCam HD)

2-1. [Ubuntu 18.04 / 20.04 64-bit]

- **SilkyEvCam\_Plugin\_Installer\_for\_ubuntu\_v??.?.zip**

Please refer to the "readme.txt" file included in the above file for the setup procedure.

- Connect SilkyEvCam (VGA) / SilkyEvCam HD to your PC with a USB cable, start metavision\_studio and check that streaming images are output.

> metavision\_studio [return]

2-2. [Windows 10 64-bit]

- **SilkyEvCam\_Plugin\_Installer\_for\_win64\_v??.?.zip**

Please refer to the "readme.txt" file included in the above file for the setup procedure.

- Connect SilkyEvCam (VGA) / SilkyEvCam HD to your PC with a USB cable, start metavision\_studio.exe from the application menu, and check that the streaming image is output.

> metavision\_studio.exe

-----  
Manufacturer : CenturyArcs Co., Ltd.

Location : 3-13-1 Nishi-Azabu, Minato-ku, Tokyo 106-0031 TEL: +81-3-6804-5752

Web site : <https://www.centuryarks.com/>

Product Inquiries Email : [ca-qa@centuryarks.com](mailto:ca-qa@centuryarks.com)